

**AIR POGO® LIMITED WARRANTY
CLAIM PROCEDURE**

For coverage under this limited warranty, proof of the date and place of purchase must be submitted. Simply fill out the warranty information and return it to us now.

If you should need warranty service, call our Customer Service Department at **800-880-POGO (7646)**, or write Air Pogo, 520 Salem Avenue, Holly Springs, MS 38635.

This limited warranty does not apply to any part if the damage has been caused by consumer abuse, misuse, vandalism or accident. Also, present color technology does not enable us to warranty against color fading over time.

Implied warranties of merchantability or of fitness for any particular purpose are limited in duration to the 90 day warranty period as specified, although some states do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you.

Air Pogo will not, under any circumstances, be liable for any incidental or consequential damages for breach of the warranty or of any implied warranty. Again, some states do not allow the exclusion or limitation of incidental or consequential damages, so this exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. **Not applicable outside U.S.A.**

WARRANTY INFORMATION

Product Name _____ Date Purchased _____

Store/Catalog Where Purchased _____ Cost of Toy _____

Age of Purchaser: ☐ 18-24 ☐ 25-34 ☐ 35-44 ☐ 45-54 ☐ 55 & over

Purchaser is: ☐ Male ☐ Female Child is: ☐ Male ☐ Female Age of Child Receiving Toy: _____


Reason for Purchase: ☐ Birthday ☐ Christmas ☐ Other _____

How did you learn about this toy? ☐ Magazine Ad ☐ Newspaper ☐ Catalog ☐ Friend ☐ Store Display
☐ Package ☐ Other _____

Name _____
(Last) (First)

Street _____

City _____ State _____ Zip _____ Phone _____




Model # 34604, 44604, 34904, 44904

AIR POGO® OPERATING AND MAINTENANCE INSTRUCTIONS

Thank you for purchasing our award-winning AIR POGO® swing. Please read and follow all warnings and instructions, review them with your children and their playmates, and save this information for future reference.

AIR POGO® has been designed and tested for safety, however, children using it will need proper instruction and supervision. AIR POGO® is intended to be enjoyed as a bouncing swing and as a new type of pogo for children. Observing the following statements and warnings reduces the likelihood of serious or fatal injury. All instructions and warnings should be reviewed frequently.



WARN CHILDREN:


1. NOT TO use the AIR POGO® until it is properly assembled and installed by an adult.
2. NOT TO get off AIR POGO® while it is in motion and to hold both the handle and seat when dismounting,
because AIR POGO® WILL REBOUND!
3. NOT TO bounce AIR POGO® against the ground.
4. NOT TO exceed the maximum safe weight ratings: AIR POGO® models 34604/44604 were designed to be used by one child, 3 to 6 years old, weighing up to 60 pounds and models 34904/44904 by one child, 5 to 10 years old, weighing up to 90 pounds.
5. NOT TO touch the rope at any time during play.
6. NOT TO use AIR POGO® in a manner other than intended.
7. NOT TO swing empty AIR POGOs®.
8. NOT TO walk near or around swinging AIR POGOs®.
9. NOT TO use AIR POGO® if it is wet.
10. NOT TO attach items to AIR POGO® such as, but not limited to, jump ropes, clothesline, pet leashes, cables, chain and rope as they may cause a strangulation hazard.
11. NOT TO twist rope or loop it over top support bar since this may reduce the strength of the rope.
12. TO center their weight on the seat and to swing or to bounce with a gentle, rhythmic motion.
13. TO hold the handle with both hands at all times.
14. TO dress appropriately with well fitting shoes and no ponchos, scarves or other loose fitting clothing which is potentially hazardous.

INSTALLATION INSTRUCTIONS:

1. Install AIR POGO® over level ground, not less than 6 feet (1.8m) from any structure or obstruction such as a fence, garage, house, tree trunk, interfering branches, laundry line or electrical wire.
2. DO NOT install AIR POGO® over concrete, asphalt, packed earth or any other hard surface.
3. Install AIR POGO® seat, at a height of approximately 3 feet (1m) above the ground, from a substantial overhead support such as a tree limb or large swing set frame. The minimum support height is 8½ feet (2.6m). (DO NOT bounce on the ground.)
4. DO NOT attach AIR POGO® to a cantilever device such as a tree limb or swing set without first determining if the device, at the point of attachment, will support a minimum force of 300 lbs.

INSTALLATION INSTRUCTIONS: (continued)

- 5. If installed as instructed, the maximum fall height of this product is seven feet.
- 6. Secure the rope with a slip proof knot. Wrap any remaining rope around the support so that no excess rope dangles from the knot. (Our safety testing lab recommended the use of a knot instead of a clasp/fastener because of the numerous installation parameters.)
- 7. AIR POGO® can be minimally adjusted to a child’s weight by adjusting the knot; slightly raise or lower the height of the seat above the ground. AIR POGO® must not hit the ground.



(TWO HALF HITCHES:
This knot is suitable for tying your AIR POGO®
to the overhead support. You can tie
additional hitches with any excess rope.)

X3. CONSUMER INFORMATION SHEET FOR PLAYGROUND SURFACING MATERIALS

X3.1 M gfkne jHgm l lq ge eakagf H klae lkl l gnl)((((
hdq jgnf inhe flj dl afbnjakj kndaf jge dklgl jgnf knj j lj l
ffmdth af M gkhal de j f qjgge k fbnjakafngdaf l ak r j h ll jf l f lg
egf l egdl k jagnk g dlhdq jgnf afbnjak f n l hgl fladlg l d
h jlan djdj o f l afbnjq ak lg l knj nf j f jgnf hdq jgnf
inhe fl f e hgi lgi af lje af al afbnjq nkaf hgl fladg dl lakk d
na fl l l dlglgl k g c kgj af knj akd kkd d d l g nk k jagnk afbnjq l f
dlglgl j knj Hlq jgnf inhe flk gnd f n j hd gf j knj kkn
k gf j l gi kh d f o ad j kke q hh jlg hl d ae qina cdj hnj lg j
h c jl af j kg a lj a j jce nd ogg ahk af kf gj af
j n d j gfka j lg hl d k g c kgj af knj k o f afkl dl f
e af l af l kna afl hl nf j f jgnf hdq jgnf inhe fl

TABLE X3.1 Fall Height in Feet From Which a Life Threatening Head Injury Would Not Be Expected.

Type of Material	6 in. depth	9 in. depth	12 in. depth
Double Shredded Bark Mulch	6	10	11
Wood Chips	6	7	12
Fine Sand	5	6	9
Fine Gravel	5	7	10







X3.2 d P) dklkl e pae ne a l jge o a ad o gnd fgl ph l lg
knkl af da l j l f af afbnjq af dlglgl gnj a j fl dggk adknj af e l jad
a l q j afkl dl f e af l af l hl k g . l f) af go n j a k gnd
j g far l l d l afbnjak m lg dk ffgl hj n fl fge ll jo l knj af e l jad
aknk

X3.3 lakj gee f l l k g c kgj af e l jad k gnd pl f e af ae ne g . l
af dl aj lagfk jge l h jae l j g kl lagf jq inhe fl km k de jk f kh k
go n j nk adj fe q da j l d hne h jge e gna ko af l k g c kgj af
e l jad k gnd pl f af l j g fl f j j g ko af e af ae ne akl f g lae kl
a l g l hangl hgaf le knj jge hgaf l aj ldq f l l hangl gl knh g j l af
kljm l nj

X3.4 ak af gje lagf ak af l f lg klakl af ge h j af l j dlan k g c kgj af
hjgh jla k g n jagnk e l jad g h jlan d j e l jad ak j gee f gn j fgl j
go n j e l jad ak gfdj lan o f hjgh jdj e af l af l jad k k gnd
c h jag a dh f j h d f ak lge af l af g j j l hl k lje af f kk j q gj
qgnj inhe fl ga g e l jad h f kgf l lqh f a l g l hdq jgnf
inhe fl l n ad a h q g l e l jad af qgnj j f ak gkl

EASY ASSEMBLY INSTRUCTIONS

Adult Assembly Required • Tool Needed: Philips Head Screwdriver
CONTENTS: 1 - 5 ft. Center Pole with Rope; 1 - Swing Seat;
1 - Center Pole Cap; 2 - AIR POGO® Labels* & Instructions
(*AIR POGODOTS model is furnished with pogodots); 6 - Screws



- 1. Thread rope end through center hole of swing seat.
- 2. Slide seat down center pole to fit tightly against base of pole. Seat will be in correct position when resting on lip of the pole.
- 3. Insert four screws into pilot holes under seat and tighten.
- 4. Thread rope end through center pole cap and slide cap down to fit onto center pole.
- 5. Mount cap onto top of center pole using two screws and tighten.
- 6. Place two AIR POGO labels vertically on opposite sides of center pole, approximately one inch below pole cap.

* If you have AIR POGODOTS model, arrange the pogodots at random in a design of your choice on center pole.

DISPOSAL INSTRUCTIONS

The separate parts of AIR POGO® are recyclable. Please help us protect our environment.

